

A/C Relocation Pod SD286A

THIS CONSOLE WILL BE INSTALLED ON THE PASSENGER SIDE, TOWARDS THE MID SEAT POSITION OF THE VEHICLE.

CAUTION: When cutting hole in the headliner, be very cautious of A/C control wiring harness that is factory glued to the top side of the headliner located in the area of the cut out.



FIGURE 1

1) WITH THE CUT-OUT HOLE FACING TOWARDS THE FRONT OF THE VEHICLE, ALIGN THE A/C VENT CURVE OF THE TEMPLATE WITH THE TWO FACTORY A/C VENT. TRACE THE TEMPLATE WITH A FELT-TIP MARKER AND THE TEMPLATE. SCORE THE MARKED HEADLINER WITH A UTILITY KNIFE MAKING SHALLOW PASS TO AVOID SLIPPING. REPEAT DEEPER PASSES UNTIL THE HEADLINER DROP IS REMOVABLE. [SEE FIG. 1]

2) WITH YOUR HAND THROUGH THE OPENING OF THE POD, PULL THE CLIP OF THE A/C POD TO MAKE AN OPENING WITH THE CONSOLE. THE HEADLINER WILL FIT IN BETWEEN THE OPENING. [SEE FIG. 2]



FIGURE 2



FIGURE 3

3) WHILE THE HEADLINER FITS IN BETWEEN THE CLIP AND THE POD, SLIDE THE POD TOWARDS THE FORWARD POSITION OF THE VEHICLE. THIS WILL HOLD THE POD'S FORWARD POSITION IN PLACE. [SEE FIG. 3]

4) DO THE SIMILAR STEPS TO THE REAR POSITION OF THE POD AS YOU WOULD WITH [STEPS 2 & 3]. [SEE FIG. 4]



FIGURE 4



FIGURE 5

5) HAVE THE A/C CONTROL WIRE HARNESS THROUGH THE OPENING OF THE POD, CONNECT THE HARNESS TO THE FACTORY A/C CONTROL. PUSH THE A/C CONTROL UP TOWARD THE POD'S OPENING UNTIL IT FLUSHES WITH THE POD. [SEE FIG. 5]